

1 Installing the ENVI CS Software

The following procedure will guide in installation of Envi Cs application software image on all new DAP consoles used for Envi Cs magnetometer.

- Obtain the master disk from documentation # 790750
- Copy the content of this master disk on to the USB memory stick
- Connect the USB stick to DAP console USB port
- Locate **MyDevice** folder on the DAP console desk top and open it by double clicking on it.
- **Locate Hard Disk folder and open it.**
- Locate **ENVICsImage 790750** folder and open it
- Select all the files and folder in this folder by pressing EDIT (up menu) and Select ALL...copy
- Navigate to **DiskOnChip** folder in root directory and paste all to this root directory.
- Locate **DapUtilities** folder and run application **ClearOS.exe** and wait until system does its thing (may take 1-2min). When prompted with dialog say YES.
- When prompted with dialog **DubShell** select YES....wait until image setup completes.
- After system reboots 2 times the new image will be set up
- To run the application Press Shift F3 2 times until you see white screen.Press folder KEY (between blue key and ON/OFF key ...to the right of space bar button.This will install keypad driver required for Mag application
- Press Shift F1 (ONCE ONLY) this will start ENVI Cs application.